

Thor 6mm Remedial Crack Stitching/Expansion Joint Application Guide – Tolerance -0mm/+5mm				
Wall Thickness & Application		Depth of Slot	Single 6mm Thor Wire Depth	WHO Beads
110mm	Crack Stitch	35mm	25mm	2
110mm	Expansion Joint	40mm	35mm	2
230mm Solid Wall	Crack Stitch	40mm (Under Header Courses if possible)	35mm	2
230mm Solid Wall	Expansion Joint	45mm	40mm	2
270mm Cavity Wall	Crack Stitch	35mm Both Single Leaves	30mm	2
270mm Cavity Wall	Expansion Joint	40mm Both Single Leaves (Additional wall ties may be required)	35mm	2
350mm Solid Wall	Crack Stitch	45mm Both External Leaves (Under Header Courses if possible)	40mm	2
350mm Solid Wall	Expansion Joint	45mm Both External Leaves	40mm	2

