

| Thor 6mm Remedial Crack Stitching/Expansion Joint Application Guide – Tolerance -0mm/+5mm | | | | |
|--|-----------------|---|-----------------------------------|------------------|
| Wall Thickness & Application | | Depth of Slot | Single 6mm Thor Wire Depth | WHO Beads |
| 110mm | Crack Stitch | 35mm | 25mm | 2 |
| 110mm | Expansion Joint | 40mm | 35mm | 2 |
| 230mm Solid Wall | Crack Stitch | 40mm (Under Header Courses if possible) | 35mm | 2 |
| 230mm Solid Wall | Expansion Joint | 45mm | 40mm | 2 |
| 270mm Cavity Wall | Crack Stitch | 35mm Both Single Leaves | 30mm | 2 |
| 270mm Cavity Wall | Expansion Joint | 40mm Both Single Leaves (Additional wall ties may be required) | 35mm | 2 |
| 350mm Solid Wall | Crack Stitch | 45mm Both External Leaves (Under Header Courses if possible) | 40mm | 2 |
| 350mm Solid Wall | Expansion Joint | 45mm Both External Leaves | 40mm | 2 |

